Panasonic



Operating Instructions

Digital Cordless Phone
Model No. **KX-TG1831NZ**



This unit is Caller ID compatible. To display the caller's phone number, you must subscribe to Caller ID service.

Charge the batteries for about 7 hours before initial use.

Please read these operating instructions before using the unit and save them for future reference.

Introduction

Thank you for purchasing a new Panasonic digital cordless phone.

For your future reference

Attach or keep original receipt to assist with any repair under warranty.

Serial No. (found on the bottom of the base unit)

Date of purchase

Name and address of dealer

Note:

• In the event of problems, you should contact your equipment supplier in the first instance.

Preparation
Accessory information .4 Important information .5 Controls .6 Displays .7 Connections .7 Battery installation/replacement .8 Battery charge .8 Turning the power on/off .9 Symbols used in these operating instructions .9 Display language .10 Date and time .10
Making/Answering Calls
Making calls
Phonebook
Handset phonebook
Handset Settings
Handset settings
Base Unit Settings
Base unit settings
Caller ID Service
Using Caller ID service
Caller list
Multi-unit Operation
Operating additional units
Useful Information
Character entry24Error messages.26Troubleshooting.26Specifications.29

Index 30

Accessory information

Included accessories

No.	Accessory items	Quantity
1	AC adaptor for base unit (Part No. PQLV207AL)	1
2	Telephone line cord	1
3	Rechargeable batteries AAA size (Part No. HHR-55AAAB or HHR-4EPT)	2
4	Handset cover ^{*1}	1

^{*1} The handset cover comes attached to the handset.

















Additional/replacement accessories

Please contact your nearest Panasonic dealer for sales information.

No.	Model No.	Description	
1	KX-TGA183AZ	Additional Digital Cordless Handset	
2	KX-TCA717EX	Wall-Mounting Adaptor	
3	KX-TCA718EX	Belt Clip	
4	KX-A272	DECT repeater	

(2)







Note:

- When replacing the batteries, use only 2 rechargeable AAA size nickel metal hydride (Ni-MH) batteries of capacity up to 750 mAh. We recommend using Panasonic rechargeable batteries (Model No. HHR-4EPT).
- We cannot be responsible for any damage to the unit or degradation of performance which may occur from using non-Panasonic rechargeable batteries.

Important information

General

- Use only the AC adaptor included with this product, noted on page 4.
- Do not connect the AC adaptor to any AC outlet other than a standard 220–240 V AC outlet.
- This product is unable to make calls when:
 - the portable handset battery(ies) need recharging or have failed.
 - there is a power failure.
- Do not open the base unit, charger, or handset other than to replace the battery(ies).
- This product should not be used near emergency/intensive care medical equipment and should not be used by people with pacemakers.
- Care should be taken that objects do not fall onto, and liquids are not spilled into, the unit. Do not subject this product to excessive smoke, dust, mechanical vibration or shock.

Environment

- Do not use this product near water.
- This product should be kept away from heat sources such as radiators, cookers, etc. It should also not be placed in rooms where the temperature is less than 5 °C or greater than 40 °C.
- The AC adaptor is used as the main disconnect device. Ensure that the AC outlet is installed near the unit and is easily accessible.

Warning:

- To prevent the risk of electrical shock, do not expose this product to rain or any other type of moisture.
- Unplug this unit from power outlets if it emits smoke, an abnormal smell or makes

unusual noise. These conditions can cause fire or electric shock. Confirm that smoke has stopped and contact an authorised service centre.

Battery caution

- We recommend using the battery(ies) noted on page 4. Use only rechargeable battery(ies).
- Do not mix old and new batteries.
- Do not dispose of the battery(ies) in a fire, as they may explode. Check local waste management codes for special disposal instructions
- Do not open or mutilate the battery(ies).
 Released electrolyte from the battery(ies) is corrosive and may cause burns or injury to the eyes or skin. The electrolyte may be toxic if swallowed.
- Exercise care when handling the battery(ies). Do not allow conductive materials such as rings, bracelets or keys to touch the battery(ies), otherwise a short circuit may cause the battery(ies) and/or the conductive material to overheat and cause burns.
- Charge the battery(ies) in accordance with the information provided in these operating instructions.
- Only use the included base unit (or charger) to charge the battery(ies). Do not tamper with the base unit (or charger).
 Failure to follow these instructions may cause the battery(ies) to swell or explode.

General warnings:

- This equipment will be inoperable when mains power fails.
- When a failure occurs which results in the internal parts becoming accessible, disconnect the power supply cord immediately and return this unit to an authorised service centre.
- Disconnect the telecom connection before disconnecting the power connection prior

Preparation

to relocating the equipment, and reconnect the power first.


- No "111" or other calls can be made from this device during a mains power failure. This equipment shall not be set to make automatic calls to the Telecom "111" Emergency Service.
- To minimise the possibility of lightning damage, when you know that a thunderstorm is coming, we recommend that you:
 - Unplug the telephone line cord from the phone jack.
 - Unplug the AC adaptor from the AC power outlet.
- The earpiece on the handset is magnetised and may retain small metallic objects.
- This equipment has been tested and found to comply with AS/NZS 3548: 1995 limits for electromagnetic interference.
 Any modifications to any part of the system or to any peripherals may void the EMC compliance of the system or the peripherals.
- Not all telephones will respond to incoming ringing when connected to the extension socket.
- This equipment may not provide for the effective hand-over of a call to another device connected to the same line.

Important notice:

 Under power failure conditions, this telephone may not operate. Please ensure that a separate telephone, not dependent on local power, is available for emergency use.


Controls

Handset



- Speaker
- Charge contact
- ⑥ [■/OK] (Menu/OK)
- 4 [m] (Phonebook)
- **④** [**↑**] (Talk)
- 6 Navigator key ([▲]/[▼]/[►]/[◄])
- **⑦** [♣] (Speakerphone)
- (Racall)
- Charge indicator/Ringer indicator
- Receiver
- Display
- ② 【 】 (Redial/Pause)
- **(B)** [★①] (Off/Power)
- **(Clear/Mute)**
- (5) Dial keypad
- (INT) (Intercom)
- **Microphone**

Base unit



- Charge contact
- 2 [•))] (Page)
- Ringer


Displays

Display icons

Display icon	Meaning
Ψ	Within range of a base unit
	 When flashing: Handset is searching for base unit. (out of range of base unit, handset is not registered to base unit, no power on base unit)
an)	Handset is accessing base unit. (intercom, paging, changing base unit settings, etc.)
~	Handset is on an outside call.
	Battery strength
[2]	Handset number (Standby display setting, page 15)
$\boxtimes_{\mathcal{O}}$	New call minder message received (page 20)
[IN USE]	Line is being used by another handset.

Connections

When connecting the AC adaptor to the base unit, a short beep will be heard. If it is not heard, check the connections.




Note:

- Never install telephone wiring during a lightning storm.
- The AC adaptor must remain connected at all times. (It is normal for the adaptor to feel warm during use.)
- The AC adaptor should be connected to a vertically oriented or floor-mounted AC outlet. Do not connect the AC adaptor to a ceiling-mounted AC outlet, as the weight of the adaptor may cause it to become disconnected.
- The unit will not work during a power failure. We recommend connecting a standard telephone to the same telephone line or to the same telephone jack using a BT double adaptor.
- The unit is not designed to be used with rotary (pulse dialling) services.

If you subscribe to an ADSL service

- Please attach a noise filter (contact your ADSL service provider) to the telephone line between the base unit and the telephone line jack in the event of the following:
 - Noise is heard during conversations.
 - Caller ID features (page 19) do not function properly.



Location

- For maximum distance and noise-free operation, place your base unit:
 - away from electrical appliances such as TVs, radios, personal computers or other phones.
 - in a convenient, high and central location.

Battery installation/replacement


Important:

- Use only the included rechargeable batteries noted on page 4, 5.
- When replacing batteries, we recommend using the Panasonic rechargeable batteries noted on page 4, 5.
- Wipe the battery ends (⊕, ⊖) with a dry cloth.

- Install the batteries without touching the battery ends (⊕, ⊕) or the unit contacts.
- Press the notch on the handset cover firmly and slide it in the direction of the arrow.
 - When replacing batteries, remove the old batteries positive (+) terminal first.



2 Insert the batteries negative (○) terminal first. Close the handset cover.



Battery charge

Place the handset on the base unit for about 7 hours before initial use.

When charging, the battery icon is shown as follows.



When the batteries are fully charged, **TITE** remains on the display.

 The charge indicator lights up when the handset is placed on the base unit.



Note:

- It is normal for the handset to feel warm during charging.
- If you want to use the unit immediately, charge the batteries for at least 15 minutes.
- Clean the charge contacts of the handset and base unit with a soft, dry cloth once a month, otherwise the batteries may not charge properly. Clean more often if the unit is exposed to grease, dust or high humidity.

Battery strength

Battery icon	Battery strength
•••	High
	Medium
	Low When flashing: Needs to be charged.

Panasonic Ni-MH battery performance (included batteries)

Operation	Operating time
In continuous use	17 hours max.
In continuous standby mode	180 hours max.

Note:

 It is normal for batteries not to reach full capacity at the initial charge. Maximum battery performance is reached after a few

- complete cycles of charge/discharge (use).
- Actual battery performance depends on a combination of how often the handset is in use and how often it is not in use (standby).
- Battery operating time may be shortened over time depending on usage conditions and ambient temperature.
- Even after the handset is fully charged, the handset can be left on the base unit without any ill effect on the batteries.
- The battery strength may not be displayed correctly after you replace the batteries. In this case, place the handset on the base unit and charge for at least 7 hours.

Turning the power on/off

Power on

Press [> 0] for about 1 second.

Power off

Press (> 0) for about 2 seconds.

Symbols used in these operating instructions

Symbol	Meaning
[国/OK]	Press (E/OK).
\rightarrow	Proceed to the next operation.
u 19	Select the words in quotations shown on the display (e.g., "Handset Setup") by pressing (A) or (V).

Display language

- 1 [国/OK]
- 2 Press (▲) or (▼) to select "Handset Setup". → (►)
- 3 Press [A] or [V] to select "Display Setup". → [►]
- 4 Press (▲) or (▼) to select "Select Language". → (►)
- 5 Press (▲) or (▼) to select the desired language. → (►) → (★①)

Note:

If you select a language you cannot read, press [★①], press [■/OK], press [▲] 3 times, press [►], press [▼] 2 times, press [►], press [▼], select the desired language, press [►], then press [★①].

Date and time

- 1 [国/OK]
- 2 Press [A] or [V] to select "Handset Setup". → [►]
- 3 Press [A] or [V] to select "Set Date & Time". → [►]
- 4 Enter the current day, month, and year. Example: 17 May, 2006 [1][7] [0][5] [0][6]
- Enter the current hour and minute.
 Example: 3:30 PM
 [0][3][0] → Press [★] until
 "03:30 PM" is displayed.
- 6 [国/OK] → [¾①]

Note:

 To correct a digit, press (◄) or (►) to move the cursor, then make the correction. The date and time may be incorrect after a power failure. In this case, set the date and time again.

Making calls

- **1** Lift the handset and dial the phone number.
 - To correct a digit, press [C/⋈], then enter the correct number.
- 2 [~]
- 3 When finished talking, press [ఀ♠♠] or place the handset on the base unit.

Speakerphone

- 1 During a conversation, press [♣] to turn on the speakerphone.
 - Speak alternately with the caller.
- 2 When finished talking, press [★①].

Note:

- For best performance, use the speakerphone in a quiet environment.
- To switch back to the receiver, press
 [>].

To adjust the receiver or speaker volume Press (A) or (V) while on a call.

Redial feature

Previously dialled phone numbers (each 24 digits max.) can be redialled.

To make a call using the redial list

The last 10 phone numbers dialled are stored in the redial list.

- 1 [3]
- 2 Press (▲) or (▼) to select the desired number.
- 3 [一]/[岭]

To erase numbers in the redial list

- 1 [3]
- 2 Press [▲] or [▼] to select the desired number. → [▶]

- 3 "Erase" \rightarrow [\triangleright]
- 4 "Yes" \rightarrow [\triangleright] \rightarrow [\circlearrowleft 0]

Other features

Mute

While mute is turned on, you will be able to hear the other party, but the other party will not be able to hear you.

To mute your voice, press [C/⋈].

To return to the conversation, press
 [C/⋈] again.

R button (to use the recall feature)

(R) is used to access optional telephone services. Contact your service provider/telephone company for details.

Note:

- If your unit is connected to a PBX (private branch exchange), pressing [R] can allow you to access certain features of your host PBX such as transferring an extension call. Consult your PBX dealer for details.
- You can change the recall time (page 17).

Call waiting

Call waiting is a service offered by your service provider/telephone company whereby a second caller can be answered while online with the first caller. To answer the second caller, press [R]. To return to the first caller, press [R] again. Please consult your service provider/telephone company for details of this service.

Pause button (for PBX/long distance service users)

A pause is sometimes required when making calls using a PBX or long distance service.

Example: If you have to dial **(0)** before dialling outside numbers manually, you will probably need to pause after dialling **(0)** until you hear a dial tone.

- 1 $[0] \rightarrow [\infty]$

Note:

Answering calls

- 1 Lift the handset and press [↑] or [♣] when the unit rings.
 - You can also answer a call by pressing any dial key from [0] to [9], [*], [#], or [INT]. (Any key answer feature)
- 2 When finished talking, press [★①] or place the handset on the base unit.

Auto talk feature

You can answer calls simply by lifting the handset off the base unit. You do not need to press []. To turn this feature on, see page 15.

To adjust the handset ringer volume when receiving a call

Press (▲) or (▼).

Handset locator

Using this feature, you can locate the handset if it has been misplaced.

- 1 Press (•)) on the base unit.
- 2 To stop paging, press (**) on the base unit or press (**\O) on the handset.

Handset phonebook

The handset phonebook allows you to make calls without having to dial manually. You can add 50 names and phone numbers to the handset phonebook.

Adding entries to the handset phonebook

- 1 $(\square) \rightarrow (\square/OK)$
- 2 "New Entry" → [►]
- 3 Enter the party's name (16 characters max.; page 24). → [■/OK]
- 4 Enter the party's phone number (24 digits max.). → [■/OK]
- 5 "Save" \rightarrow [>] \rightarrow [\nearrow 0]

Note:

• Step 1 variation:

[■/OK] → Press [A] or [V] to select
"Ph.Book Setup". → [N]

Finding and calling a handset phonebook entry

Handset phonebook entries can be searched for by scrolling through all handset phonebook entries.

When you have found the desired entry, press [].

Scrolling through all entries

- 1 (四)
- 2 Press (▲) or (▼) to display the desired entry.

Editing entries in the handset phonebook

Changing a name, phone number

- 1 Find the desired entry (page 13). → [■/OK]
- 2 "Edit" → [►]
- 3 Edit the name if necessary (16 characters max.; page 24). → [■/OK]
- 4 Edit the phone number if necessary (24 digits max.). → [■/OK]
- 5 "Save" \rightarrow [\triangleright] \rightarrow [\uparrow 0]

Erasing entries from the handset phonebook

Erasing an entry

- 1 Find the desired entry (page 13). → [■/OK]
- 2 "Erase" → [►]
- 3 "Yes" \rightarrow [\triangleright] \rightarrow [\circlearrowleft 0]

Erasing all entries

- 1 $(\square) \rightarrow (\square/OK)$
- 2 "Erase All" → [►]
- 3 "Yes" → [►]
- 4 "Yes" \rightarrow [\triangleright] \rightarrow [\bigstar 0]

Chain dial

This feature allows you to dial phone numbers in the handset phonebook while you are on a call. This feature can be used, for example, to dial a calling card access number or bank account PIN that you have stored in the handset phonebook, without having to dial manually.

- 1 While on a call, press [__].
- 2 Press (▲) or (▼) to select the desired entry.
- 3 Press [►] to dial the number.

Handset settings

ullet When customising the handset, the current item or setting is indicated by ullet .

To customise the handset:

- 1 [国/OK]
- 2 Press [▲] or [▼] to select "Handset Setup". → [►]
- **3** Press [A] or [V] to select the desired item in the handset settings menu. $\rightarrow [V]$
- **4** Press $[\blacktriangle]$ or $[\blacktriangledown]$ to select the desired item in the sub-menu. $\longrightarrow [\blacktriangleright]$
- 5 Press [▲] or [▼] to select the desired setting then press [►] or follow the instruction in the "Feature" column of the chart.
 - To exit the operation, press [★①].

Handset settings menu	Sub-menu	Feature (default setting)
Set Date & Time	_	Date and time: page 10
Ringer Setup	Ringer Volume	Handset ringer volume (Maximum)*1
	Ext. Ringtone	Ringtones for outside calls ("Ringtone 1")*2
	Int. Ringtone	Ringtones for intercom calls ("Ringtone 3")*3
Display Setup	Standby Display	Standby mode display ("off") ^{*4}
	Select Language	Display language ("English"): page 10
	Contrast	Display contrast (Level 3)
Registration	Register H.set	page 21
Other Options	Keytones	Keytones on/off ("on")
	Auto Talk	Auto talk on/off ("Off")*5

Handset Settings

- *1 When the ringer is turned off, the handset will ring:
 - at the minimum level for intercom calls
 - at the maximum level for paging
- *2 If you select one of the melody ringtones, the ringtone will continue to sound for several seconds if the caller hangs up before you answer. You may hear a dial tone or no one on the line when you answer a call.
 - The preset melodies in this product are used with permission of @ 2004 M-ZoNE Co., Ltd.
- *3 The preset melodies in this product are used with permission of © 2004 M-ZoNE Co., Ltd.
- *4 If "Off" is selected, only current date and time are displayed.

 If "Handset Number" is selected and the current handset number is 2, "[2]" is displayed.
- *5 Auto talk feature allows you to answer calls simply by lifting the handset off the base unit. You do not need to press [].

Base unit settings

- Use the handset to customise the base unit.
- When customising the base unit, the current item or setting is indicated by .

To customise the base unit:

- 1 [国/OK]
- 2 Press (A) or (▼) to select "Base Unit Setup". → (►)
- **3** Press [\blacktriangle] or [\blacktriangledown] to select the desired item in the base unit settings menu. \longrightarrow [\blacktriangleright]
- 4 Press (▲) or (▼) to select the desired item in the sub-menu. → (►)
- 5 Press [▲] or [▼] to select the desired setting then press [►] or follow the instruction in the "Feature" column of the chart.
 - To exit the operation, press [★①].

Base unit settings menu	Sub-menu	Feature (default setting)
Ringer Volume	_	Base unit ringer volume (Medium)
Call Options	Recall/Flash	Change the recall time ("600 msec.").*1
	Area Code	page 18
	Call Restrict	page 18
Other Options	Base Unit PIN	Change base unit PIN ("0000").*2 – Enter the current 4-digit base unit PIN.
		→ Enter the new 4-digit base unit PIN. → [圖/OK]
	Repeater Mode	("Off"): page 22

^{*1} Change the recall time, if necessary, depending on the requirements of your service provider/telephone company or PBX.

^{*2} If you change the PIN, please make note of your new PIN. The unit will not reveal the PIN to you. If you forget your PIN, consult your nearest Panasonic service centre.

Call options

Selecting area codes to be deleted automatically

In some situations, phone numbers stored automatically in the Caller ID list (page 19) will include area codes. If you do not want to dial the area codes when making calls from the Caller ID list, you can store the area codes which you want the unit to delete automatically.

Example: You have stored the area code "09". If you make a call from the Caller ID list to the phone number "09-456-7890", the unit dials "456-7890".

- 1 [■/OK] → "Base Unit Setup" →
 [►]
- 2 "Call Options" \rightarrow [\triangleright]
- 3 "Area Code" \rightarrow [\triangleright]
- 4 Enter an area code (5 digits max.). → (国/OK) → (水①)

Note:

 The use of this feature can prevent a National Call from being dialled. E.g., in the case of the South Island, the "03" will be omitted and will therefore prevent a National Call to other areas of the South Island.

Setting call restriction

You can restrict selected handsets from dialling certain numbers. You can assign up to 6 phone numbers to be restricted, and select which handsets will be restricted. Storing area codes here will prevent the restricted handsets from dialling any phone number in that area code.

- 1 $[\blacksquare/OK] \rightarrow \text{"Base Unit Setup"} \rightarrow [\triangleright]$
- 2 "Call Options" → [►]
- **3** "Call Restrict" \rightarrow [\triangleright]

- **4** Enter the base unit PIN (default: "0000").
- **5** Set which handsets will be restricted by pressing the desired handset number.
 - All the registered handset numbers will be displayed.
 - Flashing numbers indicate call restriction is turned on for the corresponding handset.
 - To turn call restriction off for a handset, press the number again. The number will stop flashing.
- 6 [国/OK]
- 7 Select a memory location. → [►]
- 8 Enter the phone number or area code to be restricted (8 digits max.). → [■/OK] → [★①]
 - To erase a restricted number, press 【C/☒】.

Using Caller ID service

Important:

 This unit is Caller ID compatible. To use Caller ID features (such as displaying caller phone numbers), you must subscribe to Caller ID service. Consult your service provider/telephone company for details.

For all local and national incoming calls, your display will show the area code (e.g. 09 for Auckland) or the cellular prefix (e.g. 0274 for Telecom Cellular) followed by the caller's telephone number. An Auckland caller's number will be displayed as 09XXXXXXX. The seven X's represent the seven digits of the caller's telephone number. A caller from a 6-digit Telecom Cellular number will be displayed as 0274XXXXXX. For incoming international calls, your display may only show "0000". For business users on a Centrex line, your display will show Centrex extension numbers in the shorter extension number format used within your company.

 The Caller ID information will not be presented on incoming fax calls if Telecom FaxAbility is used.

Using toll services from Telecom or another company

Your telephone company may charge you for a local call if the number dialled has the area code prefix included. If this is unacceptable, dial only the 7-digit local number. Do not dial the [0] prefix or the area code.

Caller ID features

When an outside call is received, the caller's phone number will be displayed.

- Phone numbers of the last 50 callers will be logged in the caller list.
- When caller information is received and it matches a phone number stored in the

- unit's phonebook, the stored name will be displayed and logged in the caller list.
- If the unit is connected to a PBX system, you may not receive the caller information.
- When the caller dialled from an area which does not provide Caller ID service,
 "Out of Area" will be displayed.
- When the caller requested not to send caller information, either no information or "Private Caller" will be displayed.

Missed calls

If a call is not answered, the unit treats the call as a missed call. The number of missed calls is shown on the display. This lets you know if you should view the caller list to see who called while you were out.

Caller list

Viewing the caller list and calling back

- 1 $[\blacksquare / OK] \rightarrow "Caller List" \rightarrow [\triangleright]$
- 2 Press [v] to search from the most recent call, or press [v] to search from the oldest call
 - If the item has already been viewed or answered, "V" is displayed, even if it was viewed or answered using another handset
- 3 [一]/[峙]

Note:

 If you do not want to dial the area codes when making calls from the Caller ID list, you can store the area codes which you want the unit to delete automatically (page 18).

Editing a caller's phone number before calling back

The caller's telephone number, which is sent to your telephone from your local telephone exchange, includes "0" and an area code prefix. For local calls, "0" and the area code prefix can be omitted.

- 1 [\blacksquare /OK] \rightarrow "Caller List" \rightarrow [\triangleright]
- 2 Press (▲) or (▼) to display the desired entry.
- 3 [\blacksquare /OK] → "Edit and Call" → [\blacktriangleright]
- 4 Edit the number.
 - Press dial key ([0] to [9]) to add,
 [C/⋈] to delete.
- 5 [~]/[4]

Erasing caller information

- 1 $[\blacksquare/OK] \rightarrow \text{"Caller List"} \rightarrow [\triangleright]$
- 2 Press (▲) or (▼) to display the desired entry. → (国/OK)
- 3 "Erase" \rightarrow [\triangleright]
 - To erase all entries, select "Erase All". → [▶]
- 4 "Yes" → [►] → [べ①]

Storing caller information into the handset phonebook

- 1 $[\blacksquare / OK] \rightarrow "Caller List" \rightarrow [\triangleright]$
- 2 Press (▲) or (▼) to display the desired entry. → (国/OK)
- 3 "Add Phonebook" \rightarrow [\triangleright]
- **4** Continue from step 3, "Adding entries to the handset phonebook", page 13.

For Telecom Call Minder or TelstraClear Message Mailbox service subscribers

To receive Call Minder or Message Mailbox messages, please note the following: "Call Minder" and "Message Mailbox" are automatic answering services offered by your service provider/telephone company. If you subscribe to this service, your service provider/telephone company's voice mail system will answer calls for you when you are unavailable to answer the phone or when your line is busy. Messages are recorded by your service provider/telephone company, not your telephone. Your service provider/telephone company uses a "Stutter" dial tone (special dial tone) to indicate that you have new messages. When you have new messages, ⊠ will be displayed on the handset. Please consult your service provider/telephone company for details of this service.

Note:

If
 \sumset O
 still remains on the display even
 after you have listened to new messages,
 turn it off by pressing and holding [C/\omega]
 for 2 seconds.

Operating additional units

Additional handsets

Up to 6 handsets can be registered to the base unit. Additional handsets will give you the freedom to, for example, have an intercom call with another handset while a third handset is on an outside call. See page 4 for information on ordering additional handsets.

Important:

 The additional handset model recommended for use with this unit is noted on page 4. If other model handset is used, certain operations (handset settings, base unit settings, etc.) may not be available.

Registering a handset to the base unit

The included handset and base unit are preregistered. If for some reason the handset is not registered to the base unit (for example, Υ flashes even when the handset is near the base unit), register the handset manually (page 21).

To register an additional handset to the base unit (easy registration)

After purchasing an additional handset, register it to the base unit. Ensure that the additional handset is switched on. If it is not on, press and hold [🛪 ••] for few seconds to turn the handset on.

- 1 Lift the additional handset and press [★⊙] to put the handset in standby mode.
- 2 Press and hold (**)) on the base unit for about 3 seconds, until the registration tone sounds.

3 Place the additional handset on the base unit. The registration tone continues to sound. With the handset still on the base unit, wait until a confirmation tone sounds and ♥ stops flashing.

Note:

- If all registered handsets start ringing in step 2, press [**)) to stop. Start again from step 1.
- Charge the batteries of your additional handset for about 7 hours before initial use.
- This registration method cannot be used for handsets that have already been registered to the base unit. Register the handset manually (manual registration; page 21).

To register a handset to the base unit (manual registration)

You can register a handset to the base unit manually using the following method.

- 1 [国/OK] → "Handset Setup" →
 [►]
- 2 "Registration" → [►]
- 3 "Register H.set" \rightarrow [>]
- 4 Press and hold [**)) on the base unit for about 3 seconds, until the registration tone sounds.
 - If all registered handsets start ringing, press [•)) to stop, then repeat this step.
 - After pressing (-3)), the rest of this procedure must be completed within 1 minute.
- Wait until "Enter Base PIN" is displayed, then enter the base unit PIN (default: "0000"), then press [E]/OK].
 - When the handset has been registered successfully, ♥ will stop

flashing. If keytones are turned on (page 15), a confirmation tone will be heard.

Cancelling a handset

A maximum of 6 handsets can be registered to the base unit. A handset can cancel its own registration (or the registration of another handset) that is stored in the base unit. This will allow the base unit to "forget" the handset.

- 1 [\blacksquare /OK] \rightarrow "Base Unit Setup" \rightarrow [\blacktriangleright]
- 2 Enter "335".
- 3 "Cancel Handset" → [►]
 - The numbers of all handsets registered to the base unit are displayed.
- 4 Select the handset(s) you want to cancel, by pressing the desired handset number. → [≡]/OK]
 - The selected handset number(s) will flash.
 - To cancel a selected handset number, press the number again. The number will stop flashing.
- 5 "Yes" \rightarrow [\triangleright] \rightarrow [\nearrow 0]

Increasing the range of the base unit

You can increase the signal range of the base unit by using a DECT repeater. Please use only the Panasonic DECT repeater noted on page 4. Consult your Panasonic dealer for details.

Important:

- Before registering the repeater to this base unit, you must turn the repeater mode on.
- Do not use more than one repeater at a time.

Setting the repeater mode

- 1 [\equiv /OK] \rightarrow "Base Unit Setup" \rightarrow [\triangleright]
- 2 "Other Options" → [►]
- 3 "Repeater Mode" → [▶]
- 4 "on" or "off" \rightarrow [>] \rightarrow [\nearrow 0]

Note:

After turning repeater mode on or off, Y
will flash on the handset momentarily. This
is normal. The handset can be used once
Y stops flashing.

Intercom between handsets

Intercom calls can be made between handsets.

Example: When handset 1 calls handset 2

- 1 Handset 1: [INT] → Press [2] (desired handset number).
- 2 Handset 2: Press [১] / [ঝ] to answer.
- 3 When finished talking, press [★①].

Transferring calls between handsets

Outside calls can be transferred between 2 people.

Example: When handset 1 transfers a call to handset 2

1 Handset 1:

During an outside call, press **[INT]**. → Press **[2]** (desired handset number).

- The outside call will be put on hold.
- If there is no answer, press (INT) to return to the outside call.

2 Handset 2:

Press [↑] / [♣] to answer the page.

Handset 2 can talk with handset 1.

3 Handset 1:

To complete the call transfer, press [>0].

Transferring a call without speaking to the other handset user

- 1 During an outside call, press [INT]. → Press the desired handset number.
 - **¬** flashes to indicate the outside call is on hold.

2 [%0]

• The outside call rings at the other handset.

Note:

• If the other handset user does not answer the call within 1 minute, the call will ring at your handset again.

Character entry

The dial keys are used to enter characters and numbers. Each dial key has multiple characters assigned to it. The available character entry modes are Alphabet (ABC), Numeric (0-9), Greek (ABΓ), Extended 1 (AÄÅ), Extended 2 (SŚŠ), and Cyrillic (ABB). When in these entry modes except Numeric, you can select which character is entered by pressing a dial key repeatedly.

- Press (◄) or (►) to move the cursor.
- Press dial keys to enter characters and numbers.
- Press 【C/函】 to erase the character or number highlighted by the cursor. Press and hold 【C/函】 to erase all characters or numbers.
- Press (★) to switch between uppercase and lowercase.
- To enter another character located on the same dial key, press (►) to move the cursor to the next space, then press the appropriate dial key.

Character entry modes


Several character entry modes can be used when entering text. The characters that can be entered depend on the entry mode.

Characters available in each character entry mode


When the unit displays the character entry screen:

 $[\square] \rightarrow$ Select a character entry mode. $\rightarrow [\triangleright]$

Alphabet character table (ABC)




Numeric entry table (0-9)



Greek character table (ABΓ)




Extended 1 character table (AÄÅ)



 \bullet The following are used for both uppercase and lowercase: $\,^{\emptyset} \ \mbox{$\hat{y}$} \ \mbox{$$

Extended 2 character table (SŚŠ)



• The following are used for both uppercase and lowercase:

A Ć Č Ę Ł Ĺ Ľ Ń Ŕ Ś Š ů ỳ Ź Ż Ž

Cyrillic character table (ABB)



Error messages

Error message	Cause & solution
Memory Full	• The handset's phonebook memory is full. Erase unnecessary entries (page 13).
You must first subscribe to Caller ID.	You must subscribe to Caller ID service. Once you receive caller information after subscribing to Caller ID service, this message will not be displayed.

Troubleshooting

If you still have difficulties after following the instructions in this section, disconnect the AC adaptor and turn off the handset, then reconnect the AC adaptor and turn on the handset.

Telephone

Problem	Cause & solution
▼ is flashing.	 The handset is not registered to the base unit. Register it (page 21).
	 The handset is too far from the base unit. Move closer.
	 The AC adaptor is not connected. Check the connections.
	 You are using the handset or base unit in an area with high electrical interference. Place the handset and base unit away from interference sources, such as antennas and mobile phones.
The handset display is blank.	• The handset is not turned on. Turn the power on (page 9).
The handset will not turn on.	Make sure that the batteries are installed correctly (page 8).
	Fully charge the batteries (page 8).
	 Clean the charge contacts and charge again (page 8).
I have changed the display language to a language I cannot read.	Change the display language (page 10).

Problem	Cause & solution
I cannot make or receive calls.	 The AC adaptor or telephone line cord is not connected. Check the connections. If you are using a BT double adaptor to connect the unit, remove the adaptor and connect the unit to the phone wall socket directly. If the unit operates properly, check or replace the adaptor. Disconnect the base unit from the telephone line and connect the line to a known working telephone. If the working telephone operates properly, contact our service personnel to have the unit repaired. If the working telephone does not operate properly, contact your service provider/telephone company. You dialled a call restricted number (page 18). The unit is not designed to be used with rotary (pulse dialling) services.
The unit does not ring.	The ringer volume is turned off. Adjust the ringer volume (page 15, 17).
The batteries should be charging but the battery icon does not change.	Clean the charge contacts and charge again (page 8).
A busy tone is heard when [>] is pressed.	 The handset is too far from the base unit. Move closer and try again. Another handset is in use. Wait and try again later.
Static is heard, sound cuts in and out. Interference from other electrical units.	 Place the handset and the base unit away from other electrical appliances. Move closer to the base unit. Your unit is connected to a telephone line with ADSL (JetStream) service. We recommend that you contact your ADSL service provider to have an ADSL Splitter installed. We do not recommend the use of generic ADSL filters. Contact your ADSL service provider for details.
Noise is heard during a call.	You are using the handset or base unit in an area with high electrical interference. Place the handset and base unit away from interference sources, such as antennas and mobile phones.
The handset stops working while being used.	Disconnect the AC adaptor and turn off the handset. Connect the AC adaptor, turn on the handset and try again.
Pressing () does not display/dial the last number dialled.	The redialled number was more than 24 digits long. Redial the number manually.
The handset beeps intermittently and/or I flashes.	• Fully charge the batteries (page 8).

Useful Information

Problem	Cause & solution
I fully charged the batteries, but still flashes.	 Clean the charge contacts and charge again (page 8). It is time to replace the batteries (page 8).
I fully charged the batteries, but the operating time seems to be short.	 Wipe the battery ends (⊕, ⊝) and the unit contacts with a dry cloth.
Caller information is not displayed.	You must subscribe to Caller ID service.
	 Your unit is connected to a telephone line with ADSL (JetStream) service. We recommend that you contact your ADSL service provider to have an ADSL Splitter installed. We do not recommend the use of generic ADSL filters. Contact your ADSL service provider for details. Other telephone equipment such as a monitored Burglar Alarm or the modem in the SKY Digital decoder may be interfering with this unit.
	Disconnect the other equipment and try again.
While viewing caller information, the display returns to standby mode.	Do not pause for over 1 minute while searching.
I cannot register a handset to the base unit.	 The maximum number of handsets (6) are already registered to the base unit. Cancel unused handset registrations from the base unit (page 22). You entered the wrong PIN number. If you forget your PIN, consult your nearest Panasonic service centre.
	Place the handset and the base unit away from other electrical appliances.

Specifications

■ Standard:

GAP (Generic Access Profile)

■ Number of channels:

120 Duplex Channels

■ Frequency range:

1.88 GHz to 1.9 GHz

■ Duplex procedure:

TDMA (Time Division Multiple Access)

■ Channel spacing:

1,728 kHz

■ Bit rate:

1.152 kbit/s

■ Modulation:

GFSK (Gaussian Frequency Shift Keying)

■ RF transmission power:

Approx. 250 mW

■ Power source:

220-240 V, 50 Hz

■ Power consumption:

Base unit:

Standby: Approx. 1.9 W Maximum: Approx. 6.8 W

■ Operating conditions:

5 °C–40 °C, 20 %–80 % relative air humidity (dry)

■ Dimensions:

Base unit: Approx. 60 mm \times 173 mm \times

105 mm

Handset: Approx. 155 mm \times 48 mm \times

34 mm

■ Mass (weight):

Base unit: Approx. 220 g Handset: Approx. 140 g

Note:

- Specifications are subject to change.
- The illustrations used in these operating instructions may differ slightly from the actual product.

Index

A Additional handsets: 21 Answering calls: 12 Auto talk: 12, 15

B Base unit Settings: 17 Battery

> Charge: 8 Installation: 8 Performance: 9 Replacement: 8 Strength: 9

C Caller ID service: 19
Call minder: 20
Call restriction: 18
Call waiting: 11
Chain dial: 14
Character entry: 24
Connections: 7

D Date and time: 10

Display

Contrast: 15 Icons: 7 Language: 10 Standby mode: 15

H Handset

Cancelling: 22 Locator: 12 Power on/off: 9 Registration: 21 Settings: 15

I Intercom: 22
K Keytones: 15

M Making calls: 11 Missed calls: 19

Mute: 11

P Pause: 12

Phonebook Handset phonebook: 13

PIN

Base unit: 17 Power on/off: 9 R Recall: 11, 17 Redialling: 11
Redial list: 11
Registration: 21
Repeater: 22
Ringtones: 15

S Speakerphone: 11T Transfer calls: 22

V Volume

Receiver: 11

Ringer (Base unit): 17 Ringer (Handset): 15 Speakerphone: 11

Notes

Customer Support Centre Tel. No.: (09) 272 0178

Sales Department:

Panasonic New Zealand Ltd.

350 Te Irirangi Drive East Tamaki Private Bag 14911 Panmure Auckland **NEW ZEALAND**

Panasonic Communications Zhuhai Co., Ltd.

3 Ping Xi 8 Lu, Nanping Keji Gongye Yuan, Zhuhai, Guangdong, China 519060

Copyright:

This material is copyrighted by Panasonic Communications Co., Ltd., and may be reproduced for internal use only. All other reproduction, in whole or in part, is prohibited without the written consent of Panasonic Communications Co., Ltd.

© 2006 Panasonic Communications Co., Ltd. All Rights Reserved.

